

# FORECASTER SETUP RECOMMENDATIONS



## Let's Make it Snow!

The Forecaster Snow Gun is our standard residential snow gun designed to work with a wide range of common household equipment. Since there are many equipment options, we've narrowed it down to our personal preferences. Below you will find simple setup recommendations as well as multi-train setup recommendations that we use regularly.

# SIMPLE SETUP (ONE PRESSURE WASHER)



## Standard Economic Setup (1"/hr)

Looking to make snow a couple of times each year? Here is our recommended setup:

- Forecaster Simple Package (BYSS Item)
- Rigid 5.1 CFM @ 90 PSI Compressor
- Ryobi 1.2 GPM Pressure Washer
- Rubber Garden Hose
- Extension Cords (for compressor and pressure washer)

# SIMPLE SETUP (ONE PRESSURE WASHER)



## Upgraded Simple Setup (2"/hr)

For the consistent snowmaker looking to make snow regularly during the season. Here is our recommended setup:

- Forecaster Simple Package (BYSS Item)
- Rigid 5.1 CFM @ 90 PSI Compressor
- AR 610 1.9 GPM Pressure Washer
- Rubber Garden Hose
- Extension Cords (for compressor and pressure washer)

# MULTI-TRAIN SETUP

(2+ PRESSURE WASHERS)



## Double Train Setup (2"-4"/hr)

One pressure washer not enough? Try using 2 pressure washers to increase snow output! Here are our recommended double-train setups:

- Forecaster Double Train Package (BYSS Item)
  - Rigid 5.1 CFM @ 90 PSI Compressor
  - (2) Ryobi 1.2 GPM Pressure Washers
- or (2) AR 610 1.9 GPM Pressure Washers - 4"/hr snow output
- Rubber Garden Hose
  - Extension Cords (for compressor and pressure washers)

# MULTI-TRAIN SETUP

(3+ PRESSURE WASHERS)



## Extreme Triple Train Setup (6"/hr)

Ready to max out the Forecaster? Go extreme with an upgraded Triple Train System:

- Forecaster Triple Train Package (BYSS Item)
- Rigid 5.1 CFM @ 90 PSI Compressor
- (3) AR 610 1.9 GPM Pressure Washers
- Rubber Garden Hose
- Extension Cords (for compressor and pressure washers)